


# Installation Manual

## L.TRA.EA14.C.M

Ford Transit RWD Single Tire  
(2014 →)





Ford Transit Rear wheel drive

Single tires

## L.TRA.EA14.C.M

### CONTENTS

1. FOREWORD .....	3
2. INTRODUCTION .....	4
3. VERY IMPORTANT NOTES.....	5
4. OVERVIEW .....	6
5. INSTRUCTIONS FOR INSTALLATION .....	8
5.1. Recommended Tightening Torque.....	8
5.2. Removal of Bump Stop from Chassis .....	8
5.3. Attachment of Upper Bracket to Chassis.....	9
5.4. Attachment of Bellow to Lower Bracket .....	9
5.5. Attachment of Lower Bracket to Axle .....	9
5.6. Attachment of Bellow to Upper Bracket .....	9
5.7. Fitting of Inflator Console.....	10
5.8. Tube Connection and Disconnection, Cutting and Routing .....	12
5.9. Spring Inflation.....	13
5.10. Spring Alignment .....	14
5.11. Maintenance.....	14
5.12. Installation Drawings .....	15
5.13. Check list.....	18
6. EPILOGUE .....	18

DSC Nederland B.V.  
Het Wegdam 22  
7496 CA Hengevelde  
Nederland  
Tel. : +31 (0)547 333065  
Fax. : +31 (0)547 333068  
e-mail: [info@dunlopsystems.nl](mailto:info@dunlopsystems.nl)  
Website: [www.dunlopsystems.nl](http://www.dunlopsystems.nl)

© 2017, DSC Nederland B.V.



Ford Transit Rear wheel drive

Single tires

## L.TRA.EA14.C.M

### 1. FOREWORD

This manual provides instructions for the installation of an auxiliary air suspension kit, developed specifically for the Ford Transit RWD single tires (2014 onwards). To ensure correct installation of the kit, it is strongly recommend that these instructions are read thoroughly before commencing any installation work. Installation should only be carried out by a suitably qualified mechanic or specialist installation facility. DSC Nederland will not accept any responsibility for faults or defects arising from incorrect installation, which automatically renders the guarantee invalid.

#### **IMPORTANT : Manufacturer's Declaration Form**

A manufacturer's declaration form is provided with your kit. Following installation of the kit please ensure that this form is completed, signed by a qualified fitter and a copy is returned to DSC Nederland by post, fax or e-mail. Our e-mail address is: [info@dunlopsystems.nl](mailto:info@dunlopsystems.nl)



Ford Transit Rear wheel drive

Single tires

## L.TRA.EA14.C.M

### 2. INTRODUCTION

Thank you for choosing an auxiliary air suspension kit from the range offered by *DSC Nederland*. Auxiliary air suspension is fitted in tandem with the standard steel springs of the vehicle suspension, and provides enhancements in terms of both the stability of the vehicle and the comfort of the passengers...

#### **Vehicle Levelling**

Simply by varying the air pressure in the springs, the vehicle can be levelled both front-to-rear and side-to-side. Keeping the vehicle level optimises stability, ensures correct headlamp beam distribution and reduces tyre wear arising from uneven distribution of weight.

#### **Straight Line Stability**

Straight line stability is greatly increased at higher speeds, and when subjected to buffeting from cross-winds or large overtaking vehicles.

#### **Reduced Body Roll**

Body roll when cornering or negotiating roundabouts is significantly reduced.

#### **Fatigue Reduction and Wear Compensation**

Suspension fatigue is reduced, so helping to prevent leaf springs from sagging under repeated or constant loading. Any sagging already present can be compensated-for. This is a particular benefit for motorhomes, which are always fully laden.

#### **Ride Comfort**

Air springs help to absorb shock loads from uneven road surfaces, therefore general ride quality is much improved.

**L.TRA.EA14.C.M****3. VERY IMPORTANT NOTES****Gross Vehicle Weight (GVW)**

**Air assist kits are not in themselves designed to increase the gross vehicle weight (GVW) rating of a vehicle.** They do not legally allow for carriage of a load greater than the carrying capacity stated on the data plate of the vehicle.

Do not exceed the maximum load specified by the vehicle manufacturer...

- ◆ to avoid compromising passenger safety
- ◆ to prevent possible damage to the vehicle
- ◆ for legal reasons

**Vehicle Uprating**

Despite the above words of caution, it is possible to upgrade the weight rating of your vehicle. This must be carried-out by a specialist supplier that will...

- ◆ carry out any necessary modifications in addition to fitting the air assist kit
- ◆ complete documentation as necessary to inform the Vehicle and Operator Services Agency (VOSA) – a mandatory requirement
- ◆ supply and fit a new weight plate to replace the original plate supplied with the vehicle

This process applies to United Kingdom registered vehicles. The process in other countries may be different.

**Safety Guidance Note**

The following very useful guidance note is available for free download from the *Health and Safety Executive (HSE)*...

**PM85, July 2007** *Safe recovery (and repair) of buses and coaches fitted with air suspension*


The uniform resource locator (URL) for this document is...

<http://www.hse.gov.uk/PUBNS/pm85.pdf>

## L.TRA.EA14.C.M

### 4. OVERVIEW

The diagram below is an overview of the complete assembly...





Ford Transit Rear wheel drive

Single tires

## L.TRA.EA14.C.M

Number	Part Number	Description	Quantity
1	21.11.00.1	Top bracket left and right	2
2	21.11.00.1.04.01	Lower bracket left and right	2
3	21.15.00.1.04.03	Strap Lower bracket	4
4	OP.LB.170-2.CPL	Air bellow 170/3	2
5	DIN 933 M10 x 25	Hexagon bolt	2
6	DIN 125A M10	Washer	2
7	DIN 7991 M8 x 12	Countersunk bolt	4
8	DIN 933 M8 x 16	Hexagon bolt	12
9	M8	Disc spring washer	12

Not in the assembly drawing

- Bleu and black air lines
- Tie wraps
- Inflate option
- Declaration of conformity
- Installation manual

## L.TRA.EA14.C.M

### 5. INSTRUCTIONS FOR INSTALLATION



#### Preparation and Precaution

Before beginning installation, ensure that you have sufficient clearance between the axle and the chassis. Use a jack if necessary. Install at one side of the vehicle at a time.



Pay attention to your safety at all times during installation - always use axle stands to support the vehicle!



Position the axle stands under the chassis (not the rear axle) with a clearance of approximately 25 cm between the chassis and the rear axle.

#### 5.1 Recommended Tightening Torque

During fitting of the air suspension system, it is recommended that nuts and bolts are tightened in accordance with the following table...

METRIC TORQUE CHART IN N.m		
SIZE	CLASS 8.8	CLASS 10.9
M6 x 1	9.9	14.0
M8 x 1.25	24.0	34.0
M10 x 1.5	48.0	67.0
M12 x 1.75	83.0	117.0
M16 x 2	200.0	285.0

- When both the bolt and nut are made from steel use either class 8.8 or 10.9
- For all other materials, tightening torque is left to the discretion of a person skilled in the art

The following instructions make reference to the diagrams on pages 14 to 19 inclusive.

#### 5.2 Removal of the Bump Stop from chassis

- Push the bump stop firmly side wards
- Remove the bump stop
- Unscrew the holder— photo 1, 2 and 3



**L.TRA.EA14.C.M****5.3 Attachment of Upper Bracket to Chassis**

The upper bracket is attached to the chassis in the area left vacant by removal of the bump stop.

- i. Install the top bracket at this position, with the raised edge of the bracket on the inside. Photo 4
- ii. Take care that the top bracket is position as far as possible to the outside before you tighten the bolt.

**5.4 Attachment of Bellow to Lower Bracket**

- i. Attached the bottom plate as shown to the air bellow (page 6 OVERVIEW and photo 5, page 16, left side)
- ii. Release the nut from the nipple and remove the small part of air hose (when used). This allows air into the bellow.
- iii. The edges of the bottom plate need to be on the rear side of the axle.

**5.5 Attachment of Lower Bracket to Axle**

- i. Attach now both straps by using M8 x 16 bolts and disc washers.
- ii. Take care that the straps are centrally fitted around the welded disk of the axle.
- iii. Take care that the square shaped lower bracket is installed parallel to the rear axle, otherwise the top side bolts won't fit.
- iv. Tighten the bolts equally, first finger tight.

**5.6 Attachment of Bellow to Upper Bracket**

- i. Bring the black air hose trough the left top bracket from top to bottom. Connect the black air hose to the left air bellow. (see Section 5.7)
- ii. Attach the upper bracket to the bellow using two M8 x 16mm bolts and two disc spring washers, do not tighten the bolts at this stage because the bellow may require alignment once inflated (Section 5.9, Figure 9).With the vehicle at driving level.

## L.TRA.EA14.C.M

### 5.7 Fitting of Inflator Console



Your kit is supplied with one of the inflator options shown above...

- **OPTION VALVES** : Two valves and a small bracket
- **OPTION 1** : Two valves in a console with two independent 10-bar pressure gauges
- **OPTION 2** : Two valves in a console with two independent 10-bar pressure gauges and a rocker on/off switch to operate the electric motor driven air compressor
- **OPTION 3** : Four valves (two for raising the vehicle ('UP') and two for lowering the vehicle ('DOWN')) in a console with two independent 10-bar pressure gauges. A pressure switch operates the electric motor driven air compressor to keep the air reservoir of 1.9-litre at pressure.



A special panel is available for **OPTION 1** and **OPTION 2**

## L.TRA.EA14.C.M

Mount the console in a position of your choice whereby it is firmly fixed, has some protection from the environment (particularly important for the console with gauges) and is easily accessible. Suggested possible locations include...

### 'Standard' Console...

- on the rear bumper
- at the rear beside the license plate
- on the chassis next to a rear wheel
- in a service shutter (motorhomes)
- beside the fuel cap

### 'Option 1', 'Option 2' or 'Option 3' Console...

- in the vehicle cabin, within reach and sight of the driver
- Beside, under the driver seat
- in the wall of a cupboard (motorhomes)
- in a service shutter (motorhomes)

### 'Comfort' Packages

The 'Option 2' and 'Option 3' panels, as shown above, are each part of a *Comfort Package* that is supplied with a compressor (and also an air reservoir in the case of the 'Option 3' panel) for ease of spring inflation and ride height setting. For further information please ask your dealer.




The picture below shows all of the parts of Comfort Package 'Option 2'...



Comfort Package 'Option 2'

**L.TRA.EA14.C.M****5.8 Tube Connection and Disconnection, Cutting and Routing****Connection and Disconnection**

Tubes are connected as shown by the diagrams below...



- A. Slide a nut over the end of the tube
- B. Push the tube onto the connector as far as possible
- C. Feed the nut up to the connector, fully tighten by hand and finally tighten one additional turn using spanners

**Cutting**

To achieve good sealing and air-tight fitting of tube ends to their connecting parts, it is very important to cut tubing cleanly and squarely. A dedicated guillotine action tubing cutter is recommended, or a craft knife if such a tool is not available. Do not use electrician's side cutters.



A dedicated tubing cutter -  
**Recommended**



Electrician's Side Cutters  
**NOT Recommended**

## L.TRA.EA14.C.M

### Routing

Study the underside of the vehicle and decide how to route each branch of the air circuit...

- To minimise the risk of chafing, avoid running tubing over metal edges as much as possible
- Avoid close proximity to heat sources such as the exhaust assembly
- Choose a route that provides as much protection as possible from dirt, debris and any solid objects that may impact the underside of the vehicle

It is recommended that tubes are guided alongside brake lines as much as possible.



Use cable ties ('tie wraps') to secure tubing to the chassis, taking care not to over-tighten them.

### 5.9 Spring Inflation

Once installation of the air assist kit is complete, inflate the springs via the inflator console taking careful note of the following...



#### Maximum and Minimum Pressure


**Maximum Pressure 7.0bar**      **Minimum Pressure 0.5bar**

Do not exceed 7.0bar (101psi), which is the recommended maximum charge pressure for the air springs.

The springs may be deflated if the vehicle is to be stored for a lengthy period without use, but a pressure of at least 0.5bar (7.25psi) should be maintained at all times in order to avoid possible compression damage to the springs.

## L.TRA.EA14.C.M

### 5.10 Spring Alignment



Spring out of alignment  
mounting plate axes  
offset

Spring in alignment  
mounting plates parallel  
and coaxial



#### CAUTION!

Before fully tightening the bolts that secure the air spring to the upper and lower brackets, set the vehicle at ride height (spring height approximately 18.5cm) and ensure that the springs are correctly aligned.

### 5.11 Maintenance

Following installation, it is recommended that all metal parts are coated with a protective substance such as body wax.

The system does not require very much maintenance other than...


- ◆ to maintain air pressure in the springs. Much like a tyre, the system may lose a little air over time.
- ◆ to keep the air bellows clean. It is suggested that, when washing the vehicle, the bellows are inspected and cleaned as necessary (preferable by spraying). Look in particular for stones or grit trapped between convolutes, as this may damage the bellow.
- ◆ Check before and after the winter period the wax coating. Re-wax when necessarily

## 5.12 Installation Drawings




L.TRA.EA14.C.M

1



2




3



4



5



6





## L.TRA.EA14.C.M


7



8



9



Spring out of alignment—  
mounting plate axes  
offset

Spring in alignment—  
mounting plates parallel  
and coaxial

**CAUTION!**

Before fully tightening the bolts that secure the air spring to the upper and lower brackets, set the vehicle at ride height (spring height approximately 18.5cm) and ensure that the springs are correctly aligned.

10





Ford Transit Rear wheel drive

Single tires

## L.TRA.EA14.C.M

### 5.13 Check List

Before driving the vehicle following completion of installation of the auxiliary air suspension system, please check...

- ...all bolts tightened to the recommended torque (Page 8)?
- ...air springs set in alignment (Section 5.10)?
- ...enough free space around the air springs to avoid wearing?
- ...all metal parts wax coated (Section 5.11)?
- ...manufacturer's declaration form completed and a copy returned?



A wait of 24 hours is recommended in order to ensure that the vehicle has maintained its stance and that there are no air leaks present.

## 6. EPILOGUE

DSC Nederland hopes that you enjoy the benefits that your *DUNLOP* air suspension system will provide for you. To ensure optimal performance, we advise that you have your system checked frequently by qualified personnel. As recommended in the fitting instructions, it is important to coat all the steel parts with a protective substance such as body wax.

### **IMPORTANT : Manufacturer's Declaration Form**

**A manufacturer's declaration form is provided with your kit. Following installation of the kit please ensure that this form is completed, signed by a qualified fitter and a copy is returned to DSC Nederland by post, fax or e-mail. Our e-mail address is: [info@dunlopsystems.nl](mailto:info@dunlopsystems.nl)**


As a condition of your warranty, modifications to the system may only be carried out by personnel of DSC Nederland.

### **Enquiries**

For general enquiries please contact one of our dealers. You can find them on our website.

[www.dunlopsystems.nl](http://www.dunlopsystems.nl)





DSC Nederland B.V.  
Het Wegdam 22  
7496 CA Hengevelde  
Nederland  
Tel. : +31 (0)547 333065  
Fax. : +31 (0)547 333068  
e-mail: [info@dunlopsystems.nl](mailto:info@dunlopsystems.nl)

[www.dunlopsystems.nl](http://www.dunlopsystems.nl)